

BelAir

COMPRESSED AIR TREATMENT

AHT Series Refrigerated Dryers

Installation & Operation Maintenance Manual

AHT20 - AHT350

(-1) 115/1/60 (-2) 230/1/60

MODEL:

SERIAL NUMBER:



BELAIR TECHNOLOGIES, LLC

COLORADO OFFICE
15558 E. Hinsdale Cir. Ste. B
Centennial, COLORADO 80112
TEL: (303) 287-6666
FAX: (720) 554-7758

DELAWARE OFFICE
20 Shea Way, Suite 204
Newark, DELAWARE 19713
TEL: (302) 894-1191
FAX: (302) 894-1193



STATEMENT OF WARRANTY TERMS & CONDITIONS

BelAir's refrigerated air dryers are warranted to be free of defects in materials and workmanship under proper use, installation, and application. Warranty covers parts and labor at fair market value and according to warranty labor replacement guidelines. This warranty shall be for a period of 15 months from date of shipment from our factory or other stocking facilities or 12 months from date of installation. Proof of installation date will be required. All dryers outside the U.S. and Canada carry a parts only warranty.

ALL FREIGHT DAMAGE CLAIMS ARE NOT THE RESPONSIBILITY OF THE MANUFACTURER AND ARE NOT COVERED UNDER WARRANTY AS ALL PRODUCTS ARE SHIPPED F.O.B. SHIPPER. PLEASE DIRECT ALL FREIGHT CLAIMS TO THE SHIPPER IN QUESTION.

EXCLUSIONS

ADJUSTMENTS TO THE HOT GAS AND MAINTENANCE OF FLOAT AND AUTOMATIC DRAINS AND CONDENSER COILS ARE CONSIDERED TO BE ROUTINE MAINTENANCE AND THEREFORE NON-WARRANTABLE ITEMS AND ARE THE SOLE RESPONSIBILITY OF THE END USER. CONSULT THE INSTALLATION, OPERATION AND MAINTENANCE MANUAL FOR THE ADJUSTMENT AND MAINTENANCE PROCEDURES. THE GEOMETRIC CONFIGURATION OF THE ACT HEAT EXCHANGER REQUIRES A MINIMUM 5 MICRON (1 MICRON RECOMMENDED) PREFILTER TO ENSURE THE LIFE OF THE HEAT EXCHANGER, THE PREFILTER MUST ALSO BE PROPERLY MAINTAINED.

THIS WARRANTY DOES NOT APPLY TO ANY UNIT DAMAGED BY ACCIDENT, MODIFICATION, MISUSE, NEGLIGENCE, OR MISAPPLICATION. DAMAGE TO HEAT EXCHANGERS BY EXPOSURE TO AMMONIA, ANY OTHER CORROSIVE SUBSTANCE OR SUB-FREEZING ENVIRONMENT WILL BE CONSIDERED MISUSE.

INSPECTION

Any refrigerated dryer part or material found defective will be repaired, replaced or refunded, at the sellers option free of charge, provided that BelAir is notified within the above stated warranty period. **All returns of allegedly defective equipment must have prior written authorization.** Said authorization may be obtained through our refrigerated dryer service department. All refrigerated dryers, parts, materials must be returned **freight prepaid** to the Manufacturer's factory for inspection within 30 days of return authorization date. Any shipment returned to the factory collect will be refused.

After inspection, if an item is found to be warrantable, the repaired item or replacement will be returned normal ground freight prepaid within the continental United States and Canada. In the event an item is deemed non-warranty due to improper usage, maintenance, improper installation, abuse, alteration or operator error the customer is responsible for all charges (including parts, labor or replacement costs) incurred resolving the warranty claim. Expedited shipment costs are the responsibility of the requestor. Any replacement part or material is warranted only to the extent of the remaining warranty period of the dryer or to the extent as provided by the supplier, whichever is longer.

IDENTIFICATION PLATE

The identification plate is located on the back of the dryer and shows all the primary data of the machine. Upon installation, fill in the table on the previous page with all the data shown on the identification plate. This data should always be referred to when calling the manufacturer or distributor.

The removal or alteration of the identification plate will void the warranty rights.

DISCLAIMER

The warranty does not cover any responsibility or liability for direct or indirect damages to persons, or equipment caused by improper usage or maintenance, and is limited to manufacturing defects only. Refer to BelAir Warranty policy manual for travel, mileage and special charge considerations. The warranty will be immediately voided if there are changes or alterations to the dryer.

FILTERS AND DRAINS

Filters and drains are warranted to be free from defects in material and workmanship, under proper use, installation, application and maintenance in accordance with written specifications for a period of one year from date of purchase. Elements, o-rings and float drains are considered consumable items and are warranted at installation only.

WHO TO CONTACT IF YOU HAVE A WARRANTY CLAIM:

BelAir Technologies, LLC	Phone	(302)894-1191	Delaware
		(303) 287-6666	Colorado
	Fax	(302) 894-1193	Delaware
		(720) 554-7758	Colorado

All freight damage claims should be filed within 15 working days and should be directed to the carrier.

1. SAFETY RULES

- 1.1 Definition of the Conventional Signs Used in This Manual
- 1.2 Warnings
- 1.3 Proper Use of the Dryer

2. INSTALLATION

- 2.1 Transport
- 2.2 Storage
- 2.3 Installation site
- 2.4 Installation layout
- 2.5 Correction factors
- 2.6 Connection to the Compressed Air System
- 2.7 Connection to the Mains
- 2.8 Condensate Drain

3. START UP

- 3.1 Preliminary Operations
- 3.2 First Start Up
- 3.3 Operation and Switching-Off

4. TECHNICAL CHARACTERISTICS

- 4.1 Technical Features of Dryers Series AHT 20-150 /AC (-1) 115/1/60
- 4.2 Technical Features of Dryers Series AHT 20-350 /AC (-2) 230/1/60

5. TECHNICAL DESCRIPTION

- 5.1 Control panel
- 5.2 Operation
- 5.3 Flow Diagram
- 5.4 Refrigerating compressor
- 5.5 Condenser Unit
- 5.6 Aftercooler
- 5.7 Pre-Filter (FTP Series - 3 micron)
- 5.8 Dehydration filter
- 5.9 Capillary tube
- 5.10 Alu-Dry Module
- 5.11 Hot gas by-pass valve
- 5.12 Refrigerant Pressure Switch P_A - P_B - P_V
- 5.13 T_S safety thermo-switch
- 5.14 DMC14 Electronic Instrument
- 5.15 Electronic level drain

6. MAINTENANCE, TROUBLESHOOTING, SPARES AND DISMANTLING

- 6.1 Controls and Maintenance
- 6.2 Troubleshooting
- 6.3 Suggested Spares
- 6.4 Dismantling of the Dryer

7. LIST OF ATTACHMENTS

- 7.1 Dryers Dimensions
- 7.2 Exploded View
- 7.3 Electric Diagrams

1.1 DEFINITION OF THE SAFETY SYMBOLS USED



Before attempting any intervention on the dryer, read carefully the instructions reported in this use and maintenance manual.



General warning sign. Risk of danger or possibility of damage to the machine. Read carefully the text related to this sign.



Electrical hazard. The relevant text outlines conditions which could result fatal. The related instructions must be strictly respected.



Danger hazard. Part or system under pressure.



Danger hazard. Component or system which during the operation can reach high temperature.



Danger hazard. It's absolutely forbidden to breathe the air treated with this apparatus.



Danger hazard. It's absolutely forbidden to use water to extinguish fire on the dryer or in the surrounding area.



Danger hazard. It's absolutely forbidden to operate the machine when the panels are not in place.



Maintenance or control operation to be very carefully performed by qualified personnel ¹.



Compressed air inlet connection point.



Compressed air outlet connection point.



Condensate drain connection point.



Operations which can be worked out by the operator of the machine, if qualified ¹.

NOTE : Text to be taken into account, but not involving safety precautions.



In designing this unit a lot of care has been devoted to the environment protection:

- CFC free refrigerants
- CFC free insulation parts
- Energy saving design
- Limited acoustic emission
- Dryer and relevant packaging composed of recyclable materials

Not to spoil our commitment, the user should follow the few ecological suggestions marked with this sign.

¹ Experienced and trained personnel acquainted with the relevant rules and laws, capable to perform the needed activities and to identify and avoid possible dangerous situations while handling, installing, using and servicing the machine.

1.2 WARNINGS



Compressed air is a highly hazardous energy source. Never work on the dryer with parts under pressure. Never point the compressed air or the condensate drain jet towards anybody. The user is responsible for the installation of the dryer, which has to be executed on the basis of the instructions given in the "Installation" chapter. Otherwise, the warranty will be voided and dangerous situations for the personnel and/or damages to the machine could occur.



Only qualified personnel can use and service electrically powered devices. Before attempting any maintenance action, the following conditions must be satisfied:

- Ensure that any part of the machine is under voltage and that it cannot be connected to the mains.
- Ensure that any part of the dryer is under pressure and that it cannot be connected to the compressed air system.



These refrigeration air dryers contain R134.a & R404A HFC type refrigerant fluid, not considered potential ozone depleting. Maintenance on refrigeration systems must be carried out only by refrigeration engineers according to local rules.

R134.a & R404A may be dangerous for men only if it is present in bulk concentrations. In case of leaks the room is to be aired before any intervention.



Any change to the machine or to the relevant operating parameters, if not previously verified and authorised by the Manufacturer, in addition to create the possibility of dangerous conditions will void the warranty.



Don't use water to extinguish fire on the dryer or in the surrounding area.

1.3 PROPER USE OF THE DRYER

This dryer has been designed, manufactured and tested only to be used to separate the humidity normally contained in compressed air. Any other use has to be considered improper. The Manufacturer will not be responsible for any problem arising from improper use; the user will be in any case responsible for any resulting damage. Moreover, the correct use requires the compliance with the installation conditions, in particular :

- Voltage and frequency of the mains.
- Pressure, temperature and flow-rate of the incoming air.
- Ambient temperature.

This dryer is supplied tested and fully assembled. The only operation left to the user is the connection to the plant in compliance with the instructions given in the following chapters.



The purpose of the machine is the separation of water and eventual oil particles present in compressed air. The dried air cannot be used for breathing purposes or for operations leading to direct contact with foodstuff.


This dryer is not suitable for the treatment of dirty air or of air containing solid particles.

2.1 TRANSPORT

Once verified the integrity of the packaging, place the unit near the installation point and unpack the contents.

- To move the packaged unit we suggest to use a suitable trolley or forklift. Transportation by hands is discouraged.
- Keep the dryer always in vertical position. Turning it upside down some parts could be irreparably damaged.
- Handle with care. Heavy blows could cause irreparable damage.

2.2 STORAGE



Even when packaged, keep the machine protected from severity of the weather.

Keep the dryer in vertical position, also when stored. Turning it upside down some parts could be irreparably damaged.

If not in use, the dryer can be stored in its packaging in a dust free and protected site at a maximum temperature of 115°F (46 °C), and a specific humidity not exceeding 90%. Should the stocking time exceed 12 months, please contact the manufacturer.



The packaging materials are recyclable. Each single material must be properly disposed in a manner complying with the rules in force in the destination country.

2.3 INSTALLATION SITE



Particular care is required in selecting the installation site, as an improper location could jeopardise the proper operation of the dryer.

This unit is not suitable to be used in explosive atmosphere, where risk of fire could exist, or in presence of gaseous or solid polluting material.




Don't use water to extinguish fire on the dryer or in the surrounding area.


Minimal installation requirements :

- Select a clean room dry, free from dust, and protected from atmospheric disturbances.
- The supporting area must be smooth, horizontal and able to hold the weight of the dryer.
- Minimum ambient temperature +35°F (+1.5 °C).
- Maximum ambient temperature +115°F (+46 °C).
- Leave at least 40in (1 meter) of free space on every side of the drier for ventilation purposes and maintenance operations.

The dryer doesn't require to be fixed to the supporting surface. The dryer needs to be fixed to the supporting surface only with particular installation procedures (dryer on brackets, hanging units, etc.)



2.4 INSTALLATION LAYOUT



Type A installation is suggested when the compressor operates at reduced intermittence and the total consumption equals the compressor flow rate.

Type B installation is suggested when the air consumption can consistently change with peak values highly exceeding the flow rate of the compressors. The capacity of the tank must be sized in order to compensate eventual instantaneous demanding conditions (peak air consumption).

2.5 CORRECTION FACTORS

Inlet air pressure	psig	60	80	100	120	140	160	180	200
	barg	4	5.5	7	8	10	11	12.5	14
Factor		0.79	0.91	1.00	1.07	1.13	1.18	1.23	1.27

Correction factor for ambient temperature changes (Air-Cooled):									
Ambient temperature	°F	80	90	100	105	110	115		
	°C	27	32	38	40	43	46		
Factor		1.22	1.11	1.00	0.94	0.89	0.83		

Correction factor for inlet air temperature changes:									
Air temperature	°F	140	160	175	180	195	210		
	°C	60	70	80	82	90	100		
Factor		1.25	1.14	1.02	1.00	0.91	0.80		

Correction factor for DewPoint changes:									
DewPoint	°F	35-40	41-45	46-50	51-54				
	°C	1.5-4.9	5-7	7.1-10	10.1-12				
Factor		0.80	1.00	1.08	1.12				

How to find the air flow capacity:

$$\text{Air flow capacity} = \text{Nominal duty} \times \text{Factor (F1)} \times \text{Factor (F2)} \times \text{Factor (F3)} \times \text{Factor (F4)}$$

Example:

An **AHT 150** has a nominal duty of **150 scfm (255 Nm³/h)**. What is the maximum allowable flow through the dryer under the following operating conditions:

- Inlet air pressure = 120 psig (8 barg)
- Ambient temperature = 105°F (40°C)
- Inlet air temperature = 195°F (90°C)
- Pressure DewPoint = 45°F (7°C)

Each item of data has a corresponding numerical factor as follows:

$$\text{Air flow capacity} = 150 \times 1.07 \times 0.94 \times 0.91 \times 1.00$$

= **137 scfm** → This is the maximum flow rate that the dryer can accept under these operating conditions.

How to select a suitable dryer for a given duty:

$$\text{Minimum Std. air flow rate} = \text{Design air flow} \div \text{Factor (F1)} \div \text{Factor (F2)} \div \text{Factor (F3)} \div \text{Factor (F4)}$$

Example:

The procedure here is to list the operating conditions and then to locate the corresponding numerical factors:

- Design air flow = 95 (161 Nm³/h)
- Inlet air pressure = 120 psig (8 barg)
- Ambient temperature = 105°F (40°C)
- Inlet air temperature = 195°F (90°C)
- Pressure DewPoint = 45°F (7°C)

In order to select the correct dryer model the required flow rate is to be divided by the correction factors relating to above mentioned parameters:

$$\text{Minimum Std. air flow rate} = 95 \div 1.07 \div 0.94 \div 0.91 \div 1.00$$

= **104 scfm** → Therefore the model suitable for the conditions above is **AHT 150 (150 scfm or 255 Nm³/h - nominal duty)**.

2.6 CONNECTION TO THE COMPRESSED AIR SYSTEM



Operations to be performed by qualified personnel.


Never operate with plants under pressure.

The user is responsible to ensure that the dryer will never be operated with pressure exceeding the nominal values.

Eventual over-pressure could be dangerous both for the operator and the machine.

The temperature and the amount of air entering the dryer must comply with the limits reported on the data plate. In case of treatment of air at particularly high temperatures, the installation of an aftercooler could result necessary. The cross section of the connecting piping, which must be free from dust, rust, chips and other impurities, must be consistent with the flow-rate of the dryer.

In order to facilitate the maintenance operations, we suggest installing a by-pass group, as shown in the following illustration.



Dryer	Ø [NPT-F]	A [in - mm]
AHT 5-12	1/2"	3.1/2" - 90
AHT 18-23	1"	16.3/8" - 415
AHT 30-40	1.1/4"	20.5/8" - 525
AHT 55-60	1.1/2"	26" - 660
AHT 80-100	2"	25" - 635

In realising the dryer, particular measures have been taken in order to limit the vibration which could occur during the operation.

Therefore we recommend to use connecting pipes able to insulate the dryer from possible vibrations originating from the line (flexible hoses, vibration damping fittings, etc.).

2.8 CONNECTION TO THE MAINS



The connection to the mains, to be carried out by qualified personnel, and the safety systems must comply with local rules and laws.

Before connecting the unit to the electric power, verify that the voltage and the frequency available on the mains correspond to the data reported on the data plate of the dryer. In terms of voltage, a $\pm 5\%$ tolerance is allowed.

Dryer supplied at 115/1/60 voltage comes with a mains connecting cable already installed and ending with a North-American standard plug 2 poles + ground. Dryer supplied at 230/1/60 voltage comes with a box for the connection to the mains.

The mains socket must be provided with a **mains magneto-thermal differential breaker** ($I_{\Delta n}=0.3A$), adjusted on the basis of the consumption of the dryer (see the nominal values on the data plate of the dryer).

The cross section of the power supply cables must comply with the consumption of the dryer, while keeping into account also the ambient temperature, the conditions of the mains installation, the length of the cables, and the requirements enforced by the local Power Provider.



It is mandatory to ensure the connection to the ground terminal.
Don't use adapters on the mains socket.
If necessary, have the plug replaced by qualified personnel.

2.9 CONDENSATE DRAIN



The condensate is discharged at the same pressure of the air entering the dryer.
Never point the condensate drain jet towards anybody.

The dryer comes already fitted with tubing in flexible plastics (1/4" - 6 mm or 3/8" - 10 mm diameter and 60in - 1500 mm long) for the connection to the collection plant.

The condensate drain occurs through two solenoid valves protected with a mechanical strainer. The condensate coming from the separator is previously filtered, then discharged. The solenoid valve coils are operated by the electronic control instrument.

If an electric strainer is installed, the intervention times are determined by the internal capacitive sensor (see specific paragraph).

Connect and properly fasten the condensate drain to a collecting plant or container.

The drain cannot be connected to pressurised systems.



Don't dispose the condensate in the environment.
The condensate collected in the dryer contains oil particles released in the air by the compressor.
Dispose the condensate in compliance with the local rules.
We suggest to install a water-oil separator where to convey all the condensate drain coming from compressors, dryers, tanks, filters, etc.

3.1 PRELIMINARY OPERATION



Verify that the operating parameters match with the nominal values reported on the data plate of the dryer (voltage, frequency, air pressure, air temperature, ambient temperature, etc.).

Before delivery, each dryer is submitted to accurate tests and controlled simulating real operating conditions. Nevertheless, the unit could be damaged during transportation. We therefore suggest to check the integrity of the dryer upon arrival and to keep it under control during the first hours of operation.



The start-up must be performed by qualified personnel.

It's mandatory that the engineer in charge adopt safety operational conditions complying with the local safety and accident prevention requirements.



The same engineer will be responsible for the proper and safe operation of the dryer.

Never operate the dryer if the panels are not in place.

3.2 FIRST START-UP



At the first start-up, or in case of start-up after a long inactivity period or following to maintenance operations, follow the instructions given below. The start-up must be performed by qualified personnel.

Sequence of operations (refer to paragraph 5.1 Control Panel) :

- Ensure that all the steps of the “Installation” chapter have been observed.
- Ensure that the connection to the compressed air system is correct and that the piping is suitably fixed and supported.
- Ensure that the condensate drain pipe is properly fastened and connected to a collection system or container.
- Ensure that the by-pass system (if installed) is closed.
- Ensure that the manual valve of the condensate drain circuit is open.
- Remove any packaging and other material which could obstruct the area around the dryer.
- Activate the mains switch.
- Turn on the main switch - pos. 1 on the control panel.
- Ensure that DMC14 electronic instrument is ON.
- Ensure the consumption matches with the values of the data plate.
- **Ensure the fan works properly - wait for its first interventions.**
- Allow the dryer temperature to stabilise at the pre-set value.
- Slowly open the air inlet valve.
- Slowly open the air outlet valve.
- Slowly close the central by-pass valve of the system (if installed).
- Check the piping for air leakage.
- Ensure the drain is regularly cycling - wait for its first interventions.

3.3 OPERATION AND SWITCHING OFF



Operation (refer to paragraph 5.1 Control Panel) :

- Verify the condenser for cleanliness.
- Verify that the system is powered.
- Turn on the main switch - pos. 1 on the control panel.
- Ensure that DMC14 electronic instrument is ON.
- Wait a few minutes; verify that the operating temperature displayed on electronic instrument DMC14 is correct and that the condensate is regularly drained.
- Switch on the air compressor.



Switching OFF (refer to paragraph 5.1 Control Panel) :

- Check that the temperature indicated on the DMC14 is within range.
- Switch OFF the air compressor.
- After a few minutes, switch OFF the main switch - pos. 1 of the control panel of the dryer.

NOTE : A DewPoint within 32°F (0°C) and 60°F (+15°C) displayed on the electronic controller is correct according to the possible working conditions (flow-rate, temperature of the incoming air, ambient temperature, etc.).

During the operation, the refrigerating compressor will run continuously. The dryer must remain on during the full usage period of the compressed air, even if the air compressor works intermittently.

4.1 TECHNICAL FEATURES OF DRYERS SERIES AHT 20-150 /AC (-1) 115/1/60

AHT MODEL	/ AC Air-Cooled					
	20	30	50	75	100	150
Air flow rate at nominal condition ¹						
[scfm]	20	30	50	75	100	150
[Nm ³ /h]	34	51	85	127	170	255
[NI/min]	566	850	1416	2124	2832	4248
Pressure DewPoint at nominal condition ¹	<45 – <7					
Nominal (max.) ambient temperature	100 (115) – 38 (46)					
Min. ambient temperature	35 – 1.5					
Nominal (max.) inlet air temperature	180 (210) – 82 (100)					
Nominal inlet air pressure	100 – 7					
Max. inlet air pressure	200 – 14					
Air pressure drop - Δp	1.5	2.8	4.1	3.8	3.9	5.0
[psi]	0.10	0.19	0.28	0.26	0.27	0.35
[bar]	1/2"	1/2"	1/2"	1"	1.1/4"	1.1/4"
Inlet - Outlet connections	R134.a					
Refrigerant type	R134.a					
Refrigerant quantity ³	7	7.1/2	10.1/4	14	14	20.1/2
[oz]	0.20	0.22	0.29	0.40	0.40	0.58
[kg]	290	290	290	530	590	880
Cooling air flow	500	500	500	900	1000	1500
[m ³ /h]	FTP 30	FTP 30	FTP 65	FTP 125	FTP 125	FTP 200
Pre-Filter (3 micron) ²	1650	2100	3500	4500	5800	8500
[model]	1/8	1/6	1/4	1/4+	1/3+	1/2
[Btu/h]	115/1/60					
Nominal refrigeration compressor power	115/1/60					
[HP]	240	260	390	530	650	900
Standard Power Supply ³	2.3	2.5	4.0	5.9	7.1	8.6
[PhV/Hz]	260	300	430	590	730	1050
Nominal electric absorption	2.7	3.0	4.4	6.4	7.7	10.0
[A]	< 70					
Max. electric absorption	82	88	93	112	134	146
[W]	37	40	42	51	61	66
[A]						
Max. level noise at 40in (1m)						
[dbA]						
Weight						
[lbs]						
[kg]						

¹ The nominal condition refers to an ambient temperature of 100°F (38°C) with inlet air at 600psig (40barg) and 100°F (38°C).

² Dryer is delivered with a m. filter already installed, fitted with automatic timed condensate drain.

³ Check the data shown on the identification plate.

4.2 TECHNICAL FEATURES OF DRYERS SERIES AHT 20-350 /AC (-2) 230/1/60

AHT MODEL	/ AC Air-Cooled									
	20	30	50	75	100	150	200	250	300	350
Air flow rate at nominal condition ¹										
[scfm]	20	30	50	75	100	150	200	250	300	350
[Nm ³ /h]	34	51	85	127	170	255	340	425	510	595
[NI/min]	566	850	1416	2124	2832	4248	5663	7080	8495	9910
Pressure DewPoint at nominal condition ¹	<45 – <7									
Nominal (max.) ambient temperature	100 (115) – 38 (46)									
Min. ambient temperature	35 – 1.5									
Nominal (max.) inlet air temperature	180 (210) – 82 (100)									
Nominal inlet air pressure	100 – 7									
Max. inlet air pressure	200 – 14									
Air pressure drop - Δp	1.5	2.8	4.1	3.8	3.9	5.0	4.4	4.9	4.5	4.2
[psi]	0.10	0.19	0.28	0.26	0.27	0.35	0.30	0.34	0.31	0.29
[bar]	1/2"	1/2"	1/2"	1"	1.1/4"	1.1/4"	1.1/2"	1.1/2"	2"	2"
Inlet - Outlet connections	R134.a									
Refrigerant type	R404A									
Refrigerant quantity ³	7	7.1/2	10.1/4	14	14	20.1/2	24.1/2	30	35	42
[oz]	0.20	0.22	0.29	0.40	0.40	0.58	0.70	0.85	1.00	1.20
[kg]	290	290	290	530	590	880	2060	2900	3600	3700
Cooling air flow	500	500	500	900	1000	1500	3500	5000		
[cfm]	FTP 30	FTP 30	FTP 65	FTP 125	FTP 125	FTP 200	FTP 200	FTP 300	FTP 300	FTP 450
[m ³ /h]	1450	2100	4000	4500	5800	8500	11900	17500	20400	20400
Pre-Filter (3 micron) ²	1/8	1/6	1/4	1/4+	1/3+	1/2	5/8	1.1/8	1.1/4	1.1/4
[model]	230/1/60									
Heat load	230/1/60									
Nominal refrigeration compressor power	230/1/60									
[HP]	240	290	450	550	680	900	1350	1750	2200	2300
[PhN/Hz]	1.5	2.0	2.7	3.3	4.0	4.7	6.3	8.4	10.5	11.1
Nominal electric absorption	260	320	510	610	760	1080	1560	2100	2580	2690
[W]	1.6	2.1	2.9	3.5	4.3	5.6	7.4	10.1	12.3	12.8
[A]	< 70									
Max. level noise at 40in (1m)	< 70									
[dbA]	82	88	93	112	134	146	165	185	291	304
[lbs]	37	40	42	51	61	66	75	84	132	138
[kg]										

¹ The nominal condition refers to an ambient temperature of 100°F (38°C) with inlet air at 600psig (40bar) and 100°F (38°C).


² Dryer is delivered with a.m. filter already installed, fitted with automatic timed condensate drain.

³ Check the data shown on the identification plate.


5.1 CONTROL PANEL

The control panel illustrated below is the only dryer-operator interface.

AHT 20 - 75



AHT 100 - 350



- ① Main switch
- ② Electronic control instrument DMC14
- ③ Air and refrigerating gas flow diagram

5.2 OPERATION


The dryer described in this manual basically consists of two separated circuits: a compressed air circuit, divided into two heat exchangers, and a refrigeration circuit.

The warm and humid entering compressed air goes through an air-to-air exchanger before entering the evaporator (air-to-refrigerant exchanger) where, due to the contact with the refrigeration circuit, it cools down to allow the condensation of the humidity it contains. The condensed humidity is then separated and expelled into the separator.

The cooled air goes through the air-to-air exchanger, where it partially warms up in cooling down the entering warm air (pre-refrigeration).

The refrigeration circuit needed for these operations is basically composed of a refrigeration compressor, a condenser and the evaporator, also called air-to-refrigerant exchanger.

5.3 FLOW DIAGRAM



- | | |
|---|---|
| ① Alu-Dry Module | ⑪ Capillary tube |
| a - Air-to-air heat exchanger | ⑫ T1 Temperature probe (DewPoint) |
| b - Air-to-refrigerant exchanger | ⑬ Condensate drain service valve |
| c - Condensate separator | ⑭ Y-shaped condensate drain strainer |
| ② Refrigerant pressure-switch P_B (AHT 300-350) | ⑮ Condensate drain solenoid valve |
| ③ T_S safety thermo-switch (AHT 100-350) | ⑯ Coil for cond. drain solenoid valve |
| ④ Refrigerant pressure-switch P_A (AHT 300-350) | ⑰ EC = Electronic control instrument |
| ⑤ Refrigerant pressure-switch (fan) P_V | ... |
| ⑥ Refrigerating compressor | ⑳ Aftercooler |
| ⑦ Hot gas by-pass valve | ㉑ Aftercooler fan (AHT 75-350) |
| ⑧ Condenser Unit | ㉒ Pre-Filter (FTP Series - 3 micron) |
| ⑨ Condenser fan | ㉓ Pre-Filter condensate drain solenoid valve |
| ⑩ Dehydration filter | ㉔ Pre-Filter coil for condensate drain solenoid valve |
- ➡ Compressed air flow direction ⇨ Refrigerating gas flow direction

5.4 REFRIGERATING COMPRESSOR

The refrigerating compressor is the pump of the system where the gas coming from the evaporator (low pressure side) is compressed up to the condensation pressure (high pressure side). All the compressors used are manufactured by primary companies and are designed for applications where high compression ratios and wide temperature changes are present.

The fully sealed construction is perfectly gas tight, so ensuring high-energy efficiency and long useful life. The pumping unit is supported by dumping springs, in order to consistently reduce the acoustic emission and the vibration diffusion. The electric motor is cooled down by the aspirated refrigerating gas, which goes through the coils before reaching the compression cylinders. The internal thermal protection protects the compressor from overheating and overcurrents. The protection is automatically restored as soon as the nominal temperature conditions are reached.

5.5 CONDENSER

The condenser is the element in which the gas coming from the compressor is cooled down and condensed becoming a liquid. Mechanically, it is formed by a copper tubing circuit (with the gas flowing inside) immersed in an aluminium blades package.

The cooling operation occurs via a high efficiency axial ventilator which, in applying pressure on the air contained within the dryer, forces it into the blades package.

It is mandatory that the temperature of the ambient air will not exceed the nominal values. It is important **TO KEEP THE UNIT FREE FROM DUST AND OTHER IMPURITIES**.

5.6 AFTERCOOLER

The aftercooler is the element where the incoming hot air undergoes the cooling stage. Mechanically, it is formed by a copper tubing circuit (with the compressed air flowing inside) immersed in an aluminium blades package. The cooling operation occurs via a high efficiency axial ventilator which, in applying pressure on the air contained within the dryer, forces it into the blades package. In models AHT 20-50 the aftercooler is combined with the dryer's condenser, thus forming just one heat exchanger battery, cooled by just one high efficiency axial fan.

It is mandatory that the temperature of the ambient air will not exceed the nominal values of the dryer. It is important **TO KEEP THE UNIT FREE FROM DUST AND OTHER IMPURITIES** taken in by the fan.

5.7 PRE-FILTER (FTP Series - 3 micron)

Positioned at the outlet of the aftercooler, it assures a good air cleanliness level, in addition to the complete removal of the water condensed in the aftercooler. **REPLACE THE FILTERING ELEMENT (CARTRIDGE) AT LEAST EVERY 12 MONTHS**.

5.8 DEHYDRATION FILTER

Traces of humidity and slag which could accumulate inside the chilling plant, or smudge which could occur after a long use of the dryer, could limit the lubrication of the compressor and clog the capillary tube. The function of the dehydration filter, located before the capillary tubing, is to stop the impurities, so avoiding their circulation within the system.

5.9 CAPILLARY TUBE

It consists of a piece of reduced cross section copper tubing located between the condenser and the evaporator to form a throttling against the flow of the refrigerating fluid. This throttling creates a pressure drop, which is a function of the temperature to be reached within the evaporator: the lower the capillary tube outlet pressure, the lower the evaporation temperature. The length and the diameter of the capillary tubing are accurately sized with the performance to be reached by the dryer; no maintenance/adjustment operations are necessary.

5.10 ALU-DRY MODULE

The air-to-air and the air-to-refrigerant heat exchangers plus the demister type condensate separator are housed in a unique module.

The counter-flows of compressed air in the air-to-air heat exchanger ensure maximum heat transfer. The large cross section of flow channels within the heat exchanger module leads to low velocities and reduced power requirements. The air-to-refrigerant exchanger, with counter-current flows, assure excellent performances. The generous dimensions of the exchange surface determines the correct and complete evaporation of the refrigerant (preventing liquid returning to the compressor). The high efficiency condensate separator is located within the drying module. No maintenance is required and it offers the additional advantage of creating a cold coalescing effect for excellent air drying results. The generous collection volume assures the correct operation of the dryer even with extremely damp inlet air.

5.11 HOT GAS BY-PASS VALVE

This valve injects part of the hot gas (taken from the discharge side of the compressor) in the pipe between the evaporator and the suction side of the compressor, keeping the evaporation temperature/pressure constant at approx. 36°F (+2 °C). This injection prevents the formation of ice inside the dryer evaporator at every load condition.



ADJUSTMENT

The hot gas by-pass valve is adjusted during the manufacturing testing phase. As a rule no adjustment is required; anyway if it is necessary the operation must be carried out by an experienced refrigeration engineer.

WARNING : the use of 1/4" Schrader service valves must be justified by a real malfunction of the refrigeration system. Each time a pressure gauge is connected, a part of refrigerant is exhausted.

Without compressed air flow through the dryer, rotate the adjusting screw (position A on the drawing) until the following value is reached:

Hot gas setting (R134.a) : temperature 33°F (+0.5 / -0 °K)

pressure 29 psig (+1.45 / -0 psi)

temperature 0.5°C (+0.5 / -0 °K)


pressure 2.0 barg (+0.1 / -0 bar)

Hot gas setting (R404A) : temperature 33°F (+0.5 / -0 °K)

pressure 75.4 psig (+1.45 / -0 psi)

temperature 0.5 °C (+0.5 / -0 °K)

pressure 5.2 barg (+0.1 / -0 bar)



5.12 REFRIGERANT PRESSURE SWITCH PA - PB - PV

As operation safety and protection of the dryer a series of pressure switches are installed in gas circuit.

PB : Low-pressure controller device on the pushing side (carter) of the compressor, is enabled only if the pressure drops below the pre-set value. The values are automatically reset when the nominal conditions are restored.

Calibrated pressure : R 404 A Stop 14.5 psig - Restart 72.5 psig

R 404 A Stop 1.0 barg - Restart 5.0 barg

PA : This high-pressure controller device, located on the pushing side on the compressor, is activated when the pressure exceeds the pre-set value. It features a manual-resetting button mounted on the controller itself.

Calibrated pressure : R 404 A Stop 464 psig - Manual reset

R 404 A Stop 32 barg - Manual reset

PV : Fan control pressure switch is placed at the discharge side of refrigeration compressor. It keeps the condensation temperature/pressure constant within preset limits (Air-Cooled).

Calibrated pressure : R 134.a Start 160 psig (117°F) - Stop 116 psig (97°F) - Tolerance ± 14.5 psi

R 134.a Start 11 barg (47°C) - Stop 8 barg (36°C) - Tolerance ± 1 bar


R 404 A Start 290 psig (113°F) - Stop 232 psig (97°F) - Tolerance ± 14.5 psi

R 404 A Start 20 barg (45°C) - Stop 16 barg (36°C) - Tolerance ± 1 bar

5.13 SAFETY THERMO-SWITCH T_s

To protect the operating safety and the integrity of the dryer, a thermo-switch (T_s) is installed on the refrigerant gas circuit. The thermo-switch sensor, in case of unusual supply temperatures, stops the cooling compressor before it is permanently damaged.

T_s : Manually reset the thermo-switch only after the nominal operating conditions have been restored. Unscrew the relative cap (see pos.1 in the figure) and press the reset button (see pos.2 in the figure).




Pos. 1



Pos. 2

5.14 DMC14 ELECTRONIC INSTRUMENT (AIR DRYER CONTROLLER)



- Button - access to set-up.
- Button - exit to set-up / value decrement.
- Button - condensate drain test / value increment.
- LED - dryer in alarm condition.
- LED - it shows the current temperature scale (°C).
- LED - it shows the current temperature scale (°F).
- LED - condensate drain solenoid valve activated.

The DMC14 controller performs a double function : it shows the current operating DewPoint temperature through the alphanumeric display, that is measured by a probe located at the end of the evaporator; it also controls the functioning of condensate drain solenoid valve through the cyclic electronic timer.

The LED shows any alarm condition, it can happen when :

- pressure DewPoint is too high;
- pressure DewPoint is too low;
- the probe is faulty.

If the probe is faulty, the instrument also shows “PF” message (Probe Failure), and alarm activation is immediate. In case of “DewPoint too low” condition (ASL parameter, that is fix and equal to 28.5°F or -2°C), the alarm signal is delayed of a fix time (AdL parameter) equal to 30 sec, while for “DewPoint too high” condition the value (ASH parameter) is set by the user and the signal is activated with AdH delay time, that can be also set up by the operator (the instrument is already adjusted during final test of the dryer, please see following values). When DewPoint returns into operating temperature (set range), the alarm condition is deactivated.

DMC14 allows also remote annunciation of this alarm condition of the dryer :

- with dryer off or in alarm conditions there is no voltage from terminal 4 and 9 of electronic instrument (please also see electric drawings into the attachments);
- whereas, with dryer on and correct operating DewPoint, there is voltage from terminal 4 and 9 of electronic instrument (please also see electric drawings into the attachments).

OPERATION - After dryer starting, the electronic controller displays current operating DewPoint : it shows the measured temperature in Celsius degrees (● °C) with a 0.5°C resolution, or in Fahrenheit degrees (● °F) with a 1°F resolution.

The condensate drain solenoid valve is activated for 2 seconds (Ton) - LED (●) on - each minute (ToF), if standard setting. To perform the manual test for the condensate drain, press the button.

SET-UP (PROGRAMMING)

To access the set-up, keep pressed simultaneously both and button for at least 5 seconds. In this way **programming operation will be activated** and the controller display shows the first parameter that can be set (Ton). After that, by pressing button the display shows the value set for that parameter. If the value is correct press button to confirm it and to give access on following parameters. To change the value of selected parameter, must be used and button, respectively to decrease or increase the value. All parameters that can be modified are indicated in following table :

Display	Description	Value range	Set value	Equal to
Ton	Activation time of the condensate drain solenoid valve.	01 ... 20	02	2 sec
ToF	Pause time of the condensate drain solenoid valve.	01 ... 20	01	1 min
ASH	Alarm threshold for a high DewPoint .	0.0 ... 68.0	60	60°F
AdH	ASH alarm time before signal	00 ... 20	20	20 min
SCL	Temperature scale	°C ... °F	°F	° Fahrenheit
Fixed parameters :	ASL (low DewPoint alarm) = -2°C or 28.5°F	AdL (signal delay) = 30 sec		


It is possible to exit from set-up condition in any moment, by pressing simultaneously both and button. If any operations are not made during 30 seconds, the controller exits automatically from programming operation.

5.15 ELECTRONIC LEVEL DRAIN

Instead of the usual drain system (a solenoid valve controlled by means of electronic instrument), an electronic level controlled drain can be installed as option. This drain consists of a condensate accumulator where a capacitive sensor continuously checks the level of the liquid: as soon as the accumulator is filled, the sensor passes a signal to the electronic control and a diaphragm solenoid valve will open to discharge the condensate. For a complete condensate discharge the valve opening time will be adjusted exactly for each single drain operation to avoid wasting air. No Y-shaped strainer is installed and no adjusting is required. A service valve is installed before the electronic drain in order to make check and maintenance operation easy.

AT DRYER START-UP VERIFY THAT THIS VALVE IS OPEN.

CONTROL PANEL



The control panel here illustrated allows checking of drain working.

Power : LED ON - drain ready to work / supplied

Valve : SLOW BLINKING LED - membrane solenoid valve open / discharging

Alarm : FAST BLINKING LED - drain in alarm condition

Test : button - discharge test (keep pushed for 2 seconds)

TROUBLESHOOTING



The troubleshooting and resultant service work should be carried out by qualified personnel. Before any intervention, ensure that:



- **no part of the machine is powered** and that it cannot be connected to the mains supply.
- **no part of the machine is under pressure** and that it cannot be connected to the compressed air system.

SYMPTOM

POSSIBLE CAUSE - SUGGESTED ACTION

- | | |
|--|--|
| ◆ No led lighting up. | ⇒ Verify that the system is powered.
⇒ Verify the electric wiring (internal and/or external).
⇒ Check internal printed circuit board for possible damage. |
| ◆ Pressing of Test button, but no condensate discharge. | ⇒ The service valve located before the drain is closed - open it.
⇒ The dryer is not under pressure - restore nominal condition.
⇒ Solenoid valve defective - replace the drain.
⇒ The internal printed circuit board is damaged - replace the drain. |
| ◆ Condensate discharge only when Test button is pressed. | ⇒ The capacitive sensor is too dirty - open the drain and clean the sensor plastic tube. |
| ◆ Drain keeps blowing off air. | ⇒ The diaphragm valve is dirty - open the drain and clean it.
⇒ The capacitive sensor is too dirty - open the drain and clean the sensor plastic tube. |
| ◆ Drain in alarm condition. | ⇒ The capacitive sensor is too dirty - open the drain and clean the sensor plastic tube.
⇒ The service valve located before the drain is closed - open it.
⇒ The dryer is not under pressure - restore nominal condition.
⇒ Solenoid valve defective - replace the drain. |

NOTE : When the drain is in alarm condition, the diaphragm solenoid valve will open 7.5 sec every 4 min.

6.1 CONTROLS AND MAINTENANCE



The maintenance operations must be worked out by qualified personnel.

Before any intervention, ensure that:



- **no part of the machine is powered** and that it cannot be connected to the mains supply.
- **no part of the machine is under pressure** and that it cannot be connected to the compressed air system.



Before attempting any maintenance operation on the dryer, switch it off and wait at least 30 minutes. During operation the copper piping connecting the compressor to the condenser can reach dangerous temperature able to burn the skin.



DAILY

- Verify that the DewPoint temperature displayed on the electronic instrument is correct.
- Check the proper operation of the condensate drain systems.
- Verify the condenser for cleanliness.



EVERY 200 HOURS OR MONTHLY

- With an air jet (Max. 30psi - 2 bar) blowing from inside towards outside, clean the condenser; repeat this operation blowing in the opposite way; be careful not to damage the aluminium blades of the cooling package.
- Close the manual condensate drain valve, unscrew the mechanical strainer and clean it with compressed air and a brush. Reinstall the strainer properly tight, and then open the manual valve.
- At the end, check the operation of the machine.



EVERY 1000 HOURS OR YEARLY

- Verify for tightness all the screws of the electric system and that all the “Faston” type connections are in their proper position.
- Check the conditions of the condensate drain flexible hoses, and replace if necessary.
- Replace the filter element (cartridge) of the Pre-Filter (FTP Series - 3 micron). Refer to the instructions in the user’s and maintenance manual of the filter for this operation.
- At the end, check the operation of the machine.

6.2 TROUBLESHOOTING



The troubleshooting and the eventual checks have to be worked out by qualified personnel.

Pay particular attention in case of interventions on the refrigerating circuit. The refrigerating fluid, if under pressure, while expanding could cause freezing burns and serious damage to the eyes, should it get in contact with them.







SYMPTOM

POSSIBLE CAUSE - SUGGESTED ACTION

- | | |
|--------------------------------|--|
| ◆ The dryer doesn't start. | ⇒ Verify that the system is powered.
⇒ Verify the electric wiring. |
| ◆ The compressor doesn't work. | ⇒ Activation of the compressor internal thermal protection - wait for 30 minutes, then retry.
⇒ Verify the electric wiring.
⇒ Where installed- Replace the internal thermal protection and/or the start-up relay and/or the start-up capacitor and/or the working capacitor.
⇒ Where installed- The P _A pressure switch has been activated - see specific point.
⇒ Where installed- The P _B pressure switch has been activated - see specific point.
⇒ Where installed- The T _S safety thermo-switch has been activated - see specific point.
⇒ If the compressor still doesn't work, replace it. |

- ◆ The condenser fan doesn't work .
 - ⇒ Verify the electric wiring.
 - ⇒ P_V pressure switch is faulty - replace it.
 - ⇒ If the fan still doesn't work, replace it.
- ◆ **AHT 75-350-** The Aftercooler fan doesn't work.
 - ⇒ Verify the electric wiring.
 - ⇒ If the fan still doesn't work, replace it.
- ◆ DewPoint too high.
 - ⇒ The dryer doesn't start - see specific point.
 - ⇒ The T1 DewPoint probe doesn't correctly detect the temperature - ensure the sensor is pushed into the bottom of copper tube immersion well.
 - ⇒ The refrigerating compressor doesn't work - see specific point.
 - ⇒ The ambient temperature is too high or the room aeration is insufficient - provide proper ventilation.
 - ⇒ The inlet air is too hot - restore the nominal conditions.
 - ⇒ The inlet air pressure is too low - restore the nominal conditions.
 - ⇒ The inlet air flow rate is higher than the rate of the dryer - reduce the flow rate - restore the normal conditions.
 - ⇒ The condenser unit is dirty - clean it.
 - ⇒ The aftercooler is dirty - clean it.
 - ⇒ The condenser fan doesn't work - see specific point.
 - ⇒ The aftercooler fan doesn't work - see specific point.
 - ⇒ The dryer doesn't drain the condensate - see specific point.
 - ⇒ The hot gas by-pass valve is out of setting - contact a refrigeration engineer to restore the nominal setting.
 - ⇒ There is a leak in the refrigerating fluid circuit - contact a refrigeration engineer.
- ◆ DewPoint too low.
 - ⇒ The condenser fan is always ON - P_V pressure switch is faulty.
 - ⇒ The hot gas by-pass valve is out of setting - contact a refrigeration engineer to restore the nominal setting.
- ◆ Excessive pressure drop within the dryer.
 - ⇒ The Pre-Filter (FTP Series - 3 micron) is clogged - replace the filter element (cartridge) - Refer to the instructions in the user's and maintenance manual of the filter.
 - ⇒ The dryer doesn't drain the condensate - see specific point.
 - ⇒ The DewPoint is too low - the condensate is frost and blocks the air - see specific point.
 - ⇒ Check for throttling the flexible connection hoses.
- ◆ The dryer doesn't drain the condensate.
 - ⇒ The condensate drain service valve is closed - open it.
 - ⇒ The condensate drain strainer is clogged - remove and clean it.
 - ⇒ The drain solenoid valve is jammed - remove and clean it.
 - ⇒ Verify the electric wiring.
 - ⇒ The coil of the condensate drain solenoid valve burned out - replace it.
 - ⇒ The DewPoint is too low - the condensate is frozen - see specific point.
- ◆ The dryer continuously drains condensate.
 - ⇒ The drain solenoid valve is jammed - remove and clean it.
 - ⇒ Try to remove the electric connector on the solenoid valve - if drain stops verify the electric wiring or the electronic instrument is faulty - replace it.
- ◆ Water within the line.
 - ⇒ The dryer doesn't start - see specific point.
 - ⇒ **Where installed-** Untreated air flows through the by-pass unit - close the by-pass.
 - ⇒ The dryer doesn't drain the condensate - see specific point.
 - ⇒ DewPoint too high - see specific point.

- ◆ **Where installed-** The P_A high-pressure switch has been activated. ⇒ Check which of the following has caused the activation :
1. The ambient temperature is too high or the room aeration is insufficient - provide proper ventilation.
 2. The condenser unit is dirty - clean it.
 3. The aftercooler is dirty - clean it.
 4. The condenser fan doesn't work - see specific point.
 5. The aftercooler fan doesn't work - see specific point.
- ⇒ Reset the pressure-switch pressing the button on the controller itself - verify the dryer for correct operation.
- ⇒ The P_A pressure switch is faulty - contact a refrigeration engineer to replace it.
- ◆ **Where installed-** The P_B low-pressure switch has been activated. ⇒ There is a leak in the refrigerating fluid circuit - contact a refrigeration engineer.
- ⇒ The pressure switch restores automatically when normal conditions are restored - check the proper operation of the dryer.
- ◆ **Where installed -** The T_S safety thermo-switch has been activated. ⇒ Check which of the following has caused the activation :
1. Excessive thermal load - restore the standard operating conditions.
 2. The inlet air is too hot - restore the nominal conditions.
 3. The ambient temperature is too high or the room aeration is insufficient - provide proper ventilation.
 4. The condenser unit is dirty - clean it.
 5. The aftercooler is dirty - clean it.
 6. The condenser fan doesn't work - see specific point.
 7. The aftercooler fan doesn't work - see specific point.
 8. There is a leak in the refrigerating fluid circuit - contact a refrigeration engineer.
- ⇒ Reset the thermo-switch by pressing the button on the thermo-switch itself - verify the correct operation of the dryer (also see par. 5.14).
- ⇒ The T_S thermo-switch is faulty - replace it.
- ◆ **DMC14-** The LED  • of the instrument is on or flashes to indicate alarm situations.
- ⇒ The LED  • flashes because the DewPoint is too high - see specific point.
- ⇒ The LED  • flashes because the DewPoint is too low - see specific point.
- ⇒ The LED  • flashes because the probe is faulty or interrupted, the instrument displays the message "PF" (Probe Failure) - replace the probe.

6.3 SUGGESTED SPARE PARTS

The suggested spare parts list will enable you to promptly intervene in case of abnormal operation, so avoiding to wait for the spares delivery. In case of failure of other parts, for example inside the refrigerating circuit, the replacement must be worked out by a refrigerating systems specialist or in our factory.

No.	DESCRIPTION OF THE SPARE PARTS	CODE	AHT					
			20	30	50	75	100	150
3	T _S safety thermo-switch	56141NN005					1	1
4	Refrigerant gas pressure switch P _V	5655NNN160	1	1	1	1	1	1
6	Refrigerating compressor (-1) 115/1/60	5015135101	1					
6	Refrigerating compressor (-1) 115/1/60	5015135103		1				
6	Refrigerating compressor (-1) 115/1/60	5015135007			1			
6	Refrigerating compressor (-1) 115/1/60	5015135010				1		
6	Refrigerating compressor (-1) 115/1/60	5015135011					1	
6	Refrigerating compressor (-1) 115/1/60	5030135005						1
6	Refrigerating compressor (-2) 230/1/60	5015110101	1					
6	Refrigerating compressor (-2) 230/1/60	5015110104		1				
6	Refrigerating compressor (-2) 230/1/60	5015110113			1			
6	Refrigerating compressor (-2) 230/1/60	5015110115				1		
6	Refrigerating compressor (-2) 230/1/60	5015110016					1	
6	Refrigerating compressor (-2) 230/1/60	5030115005						1
8	Hot gas by-pass valve	64140SS150	1	1	1	1	1	
8	Hot gas by-pass valve	64140SS155						1
9.1	Fan motor (-1) 115/1/60	5210135010				1		
9.1	Fan motor (-1) 115/1/60	5210135020	1	1	1		1	1
9.1	Fan motor (-2) 230/1/60	5210110012				1		
9.1	Fan motor (-2) 230/1/60	5210110018	1	1	1		1	1
9.2	Fan blade	5215000022	1	1	1			
9.2	Fan blade	5215000019				1		
9.2	Fan blade	5215000025					1	1
9.3	Fan grid	5225000010	1	1	1	1		
9.3	Fan grid	5225000027					1	1
10	Dehydration filter	6650SSS007	1	1	1	1	1	
10	Dehydration filter	6650SSN150						1
12	Temp. probe DMC14 (T1)	5625NNN035	1♦	1♦	1♦	1♦	1♦	1♦
13+14	Condensate drain valve/strainer	64355MN012	1	1	1	1	1	
14	Y-type condensate drain strainer	64355FF011						1
15	Condensate drain solenoid valve	64320FF006	1♦	1♦	1♦	1♦	1♦	1♦
16	Coil for cond. drain solenoid valve 115V	64N22MM018	1♦	1♦	1♦	1♦	1♦	1♦
16	Coil for cond. drain solenoid valve 230V	64N22MM021	1♦	1♦	1♦	1♦	1♦	1♦
17	DMC14 Electronic Instrument 115V	5620130103	1♦	1♦	1♦	1♦	1♦	1♦
17	DMC14 Electronic Instrument 230V	5620110103	1♦	1♦	1♦	1♦	1♦	1♦
21	Electronic drain (-1) 115/1/60	2210BEK015P	1	1	1	1	1	1
21	Electronic drain (-1) 230/1/60	2210BEK015A	1	1	1	1	1	1
22	Main switch 2P 0/1	5450SZN010	1	1	1	1	1	1
22	Main switch 2P 0/1 Cover	5450SZN015	1	1	1	1	1	1
27.1	Fan motor - Aftercooler (-1) 115/1/60	5210135020				1	1	
27.1	Fan motor - Aftercooler (-1) 115/1/60	5210135021						1
27.1	Fan motor - Aftercooler (-2) 230/1/60	5210110018				1	1	
27.1	Fan motor - Aftercooler (-2) 230/1/60	5210110022						1
27.2	Fan blade - Aftercooler	5215000022				1		
27.2	Fan blade - Aftercooler	5215000025					1	
27.3	Fan blade - Aftercooler	5215000032						1
27.3	Fan grid - Aftercooler	5225000015				1		
27.3	Fan grid - Aftercooler	5225000025					1	1
28.1	Cartridge for FTP 30 Pre-Filter	15000TP30	1	1				
28.1	Cartridge for FTP 65 Pre-Filter	15000TP65			1			
28.1	Cartridge for FTP 125 Pre-Filter	15000TP125				1	1	
28.1	Cartridge for FTP 200 Pre-Filter	15000TP200						1
29	Pre-Filter condensate drain solenoid valve	64320FF006	1	1	1	1	1	1
30	Pre-Filter coil x cond. drain solenoid valve 115V	64N22MM018	1	1	1	1	1	1
30	Pre-Filter coil x cond. drain solenoid valve 230V	64N22MM021	1	1	1	1	1	1

No.	DESCRIPTION OF THE SPARE PARTS	CODE	AHT			
			200	250	300	350
2	Refrigerant gas pressure switch P _B	5655NNN085			1	1
3	T _S safety thermo-switch	56141NN005	1	1	1	1
4	Refrigerant gas pressure switch P _A	5655NNN087			1	1
5	Refrigerant gas pressure switch P _V	5655NNN160	1	1	1	1
6	Refrigerating compressor	5030115015	1			
6	Refrigerating compressor	5030115020		1		
6	Refrigerating compressor	5030115025			1	1
7	Hot gas by-pass valve	64140SS155	1	1	1	1
9.1	Fan motor (Condenser)	5210110022	1			
9.2	Fan blade (Condenser)	5215000035	1			
9.3	Fan grid (Condenser)	5225000030	1			
9	Complete fan	5250110100		1	1	
9	Complete fan	5250115005				1
10	Dehydration filter	6650SSN160	1	1	1	1
12	Temp. probe DMC14 (T1)	5625NNN035	1♦	1♦	1♦	1♦
14	Y-type condensate drain strainer	64355FF011	1	1	1	1
15	Condensate drain solenoid valve	64320FF011	1♦	1♦	1♦	1♦
16	Coil for cond. drain solenoid valve	64N22MM021	1♦	1♦	1♦	1♦
17	DMC14 Electronic Instrument	5620110103	1♦	1♦	1♦	1♦
21	Electronic drain	2210BEK010A	1	1	1	1
22	Main switch	5450SZN117	1	1	1	1
27	Complete fan (Aftercooler)	5250115005	1	1		
27	Complete fan (Aftercooler)	5250110110			1	1
28.1	Cartridge for FTP 200 Pre-Filter	15000TP200	1			
28.1	Cartridge for FTP 300 Pre-Filter	15000TP300		1	1	
28.1	Cartridge for FTP 450 Pre-Filter	15000TP450				1
29	Pre-Filter condensate drain solenoid valve	64320FF011	1	1	1	1
30	Pre-Filter coil x condensate drain solenoid valve	64N22MM021	1	1	1	1

♦ Suggested spare part.

NOTE : To order the suggested spare parts or any other part, it is necessary to quote the data reported on the identification plate.

6.4 DISMANTLING OF THE DRYER

If the dryer is to be dismantled, it has to be split into homogeneous groups of materials.



Part	Material
Refrigerant fluid	R404A – HFC, R134.a – HFC, Oil
Canopy and Supports	Carbon steel, Epoxy paint
Refrigerating compressor	Steel, Copper, Aluminium, Oil
Alu-Dry Module	Aluminium
Condenser Unit	Aluminium, Copper, Carbon steel
Aftercooler	Aluminium, Copper, Carbon steel
Pipe	Copper
Fan	Aluminium, Copper, Steel
Valve	Brass, Steel
Electronic Level Drain (optional)	PVC, Aluminium, Steel
Insulation Material	Synthetic rubber without CFC, Polystyrene, Polyurethane
Electric cables	Copper, PVC
Electric Parts	PVC, Copper, Brass



We recommend to comply with the safety rules in force for the disposal of each type of material. The chilling fluid contains droplets of lubrication oil released by the refrigerating compressor. Do not dispose this fluid in the environment. It has to be discharged from the dryer with a suitable device and then delivered to a collection centre where it will be processed to make it reusable.

7.1 DRYERS DIMENSIONS

- 7.1.1 AHT 20-50 Dryers Dimensions
- 7.1.2 AHT 75 Dryers Dimensions
- 7.1.3 AHT 100 Dryers Dimensions
- 7.1.4 AHT 150 Dryers Dimensions
- 7.1.5 AHT 200-250 Dryers Dimensions
- 7.1.6 AHT 300-350 Dryers Dimensions

7.2 EXPLODED VIEW

- 7.2.1 Exploded view of Dryers AHT 20-50
- 7.2.2 Exploded view of Dryers AHT 75
- 7.2.3 Exploded view of Dryers AHT 100
- 7.2.4 Exploded view of Dryers AHT 150
- 7.2.5 Exploded view of Dryers AHT 200-250
- 7.2.6 Exploded view of Dryers AHT 300-350

Exploded view table of components - Dryers AHT 20-350

① Alu-Dry Module	②② Main switch
1.1 Insulation Material	...
② Refrigerant pressure-switch P _B (AHT 300-350)	②⑥ Aftercooler
③ T _S safety thermo-switch (AHT 100-350)	②⑦ Aftercooler fan (AHT 75-350)
④ Refrigerant pressure-switch P _A (AHT 300-350)	27.1 Motor
⑤ Refrigerant pressure-switch (fan) P _V	27.2 Blade
⑥ Refrigerating compressor	27.3 Grid
⑦ Hot gas by-pass valve	②⑧ Pre-Filter (FTP Series - 3 micron)
⑧ Condenser Unit	②⑨ Pre-Filter condensate drain solenoid valve
⑨ Condenser fan	③⑩ Pre-Filter coil for cond. drain solenoid valve
9.1 Motor	...
9.2 Blade	⑤① Front panel
9.3 Grid	⑤② Back panel
⑩ Dehydration filter	⑤③ Right lateral panel
⑪ Capillary tube	⑤④ Left lateral panel
⑫ T1 Temperature probe (DewPoint)	⑤⑤ Cover
⑬ Condensate drain service valve	⑤⑥ Base plate
⑭ Y-shaped condensate drain strainer	⑤⑦ Upper plate
⑮ Condensate drain solenoid valve	⑤⑧ Support beam
⑯ Coil for cond. drain solenoid valve	⑤⑨ Support bracket
⑰ Electronic control instrument	⑥⑩ Control panel
...	⑥① Electric connector
⑳ Electronic level drain	⑥② Electric box

7.3 ELECTRIC DIAGRAMS

- 7.3.1 *Electrical Diagram of Dryers AHT 20-50 - Electronic Instrument DMC14 (-1) 115/1/60*
- 7.3.2 *Electrical Diagram of Dryers AHT 20-50 - Electronic Instrument DMC14 (-2) 230/1/60*
- 7.3.3 *Electrical Diagram of Dryers AHT 75-100 - Electronic Instrument DMC14 (-1) 115/1/60*
- 7.3.4 *Electrical Diagram of Dryers AHT 75-100 - Electronic Instrument DMC14 (-2) 230/1/60*
- 7.3.5 *Electrical Diagram of Dryers AHT 150 - Electronic Instrument DMC14 (-1) 115/1/60*
- 7.3.6 *Electrical Diagram of Dryers AHT 150-250 - Electronic Instrument DMC14 (-2) 230/1/60*
- 7.3.7 *Electrical Diagram of Dryers AHT 300-350 - Electronic Instrument DMC14 (-2) 230/1/60*

Electrical Diagram table of components - Dryers AHT 20-350

- IG** : Main switch
- K** : Refrigerating compressor
 - KT** : Compressor thermal protection
 - KR** : Compressor starting relay (if installed)
 - CS** : Compressor starting capacitor (if installed)
 - CR** : Compressor operating capacitor (if installed)
- Va** : Aftercooler fan (Aftercooler - AHT 75-350)
 - CVA** : Aftercooler fan starting capacitor (if installed)
- Vc** : Condenser fan
 - CVC** : Fan starting capacitor (if installed)
- DMC14** : DMC14 Electronic Instrument - Air Dryer Controller
- PR** : T1 Temperature probe (DewPoint)
- PV** : Pressure switch - Fan control
- PA** : Pressure switch - Compressor discharge side - high-pressure (AHT 300-350)
- PB** : Pressure switch - Compressor suction side - low-pressure (AHT 300-350)
- TS** : Safety thermo-switch (AHT 100-350)
- BOX** : Electric box
- EVD** : Condensate drain solenoid valve
- ELD** : Electronic level drain


- BN = BROWN
- BU = BLUE
- BK = BLACK
- YG = YELLOW/GREEN




ATTACHMENTS




7.1.1 AHT 20-50




7.1.2 AHT 75




7.1.3 AHT 100




7.1.4 AHT 150




7.2.1 AHT 20-50




7.2.2 AHT 75




7.2.3 AHT 100




7.2.4 AHT 150




7.3.1 AHT 20-50 (-1) 115/1/60




7.3.2 AHT 20-50 (-2) 230/1/60




7.3.3 AHT 75-100 (-1) 115/1/60




7.3.4 AHT 75-100 (-2) 230/1/60




7.3.5 AHT 150 (-1) 115/1/60



7.3.6 AHT 150-250 (-2) 230/1/60



7.3.7 AHT 300-350 (-2) 230/1/60





T e c h n o l o g i e s , L L C

20 Shea Way, Suite 204., Newark, Delaware • TEL. (302) 894-1191 • FAX (302) 894-1193