


Repair Manual

Gas Kettles

Model KGM



0785

Cleveland Range, Inc.

UNITED STATES

1333 East 179th St., Cleveland, Ohio 44110
Phone: (216) 481-4900 • Telex: 98-0546 • FAX: (216) 481-3782

CANADA

Garland Commercial Ranges
1177 Kamato Road
Mississauga, Ontario, Canada L4W1X4
Phone: (416) 624-0260 • FAX: (416) 624-0623

KET-08

Cleveland WARRANTY AND LIMITED EXTENDED WARRANTY COVERAGE

LIMITED WARRANTY

Cleveland Range products are warranted to the original purchaser to be free from defects in material and workmanship under normal use and service for the standard warranty period.

Cleveland Range agrees to repair or replace, at its option, f.o.b. factory, any part which proves to be defective due to defects in material or workmanship during the warranty period, providing the equipment has been unaltered, and has been PROPERLY INSTALLED, MAINTAINED, AND OPERATED IN ACCORDANCE WITH THE CLEVELAND RANGE OWNER'S MANUAL.

CLEVELAND RANGE agrees to pay any FACTORY AUTHORIZED EQUIPMENT SERVICE AGENCY (within the continental United States, Hawaii, and Canada) for reasonable labor required to repair or replace, at our option, f.o.b. factory, any part which proves to be defective due to defects in material or workmanship, during the labor warranty period. This warranty includes travel time not to exceed two hours and mileage not to exceed 50 miles (100 miles round-trip), but does not include post start-up, tightening loose fittings, minor adjustments, maintenance, cleaning or descaling.

The standard labor warranty allows factory payment of reasonable labor required to repair or replace such defective parts. Cleveland Range will not reimburse the expense of labor required for the repair or replacement of parts after the standard warranty period, unless an Extended Labor Warranty Contract has been purchased to cover the equipment for the balance of the warranty period from the date of equipment installation, start-up, or demonstration.

PROPER INSTALLATION IS THE RESPONSIBILITY OF THE DEALER, THE OWNER-USER, OR INSTALLING CONTRACTOR, AND IS NOT COVERED BY THIS WARRANTY. Many local codes exist, and it is the responsibility of the owner and installer to comply with these codes. Cleveland Range equipment is built to comply with applicable standards for manufacturers, including UL, A.G.A., NSF, ASME/Int. Bd., CSA, CGA, ETL, and others.

BOILER (Steam Generator) MAINTENANCE IS THE RESPONSIBILITY OF THE OWNER-USER, AND IS NOT COVERED BY THIS WARRANTY. The use of good quality feed water is the responsibility of the Owner-User (see *Water Quality Requirements below*). THE USE OF POOR QUALITY FEED WATER WILL VOID EQUIPMENT WARRANTIES. Boiler maintenance supplies, including boiler hand gaskets, are not warranted beyond the first 90 days after the date the equipment is placed into service if no preventive maintenance records are available showing descaling every 90-120 days.

WATER QUALITY REQUIREMENTS

| | | |
|------------------------|--------------|----------------------|
| TOTAL DISSOLVED SOLIDS | less than | 60 parts per million |
| TOTAL ALKALINITY | less than | 20 parts per million |
| SILICA | less than | 13 parts per million |
| CHLORIDE | less than | 30 parts per million |
| pH FACTOR | greater than | 7.5 |

The foregoing shall constitute the sole and exclusive remedy of original purchaser and the full liability of Cleveland Range for any breach of warranty. THE FOREGOING IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL, OR IMPLIED, INCLUDING ANY WARRANTY OF PERFORMANCE, MERCHANTABILITY, OR FITNESS FOR PURPOSE, AND SUPERSEDES AND EXCLUDES ANY ORAL WARRANTIES OR REPRESENTATIONS, OR WRITTEN WARRANTIES OR REPRESENTATIONS, NOT EXPRESSLY DESIGNATED IN WRITING AS A "WARRANTY" OR "GUARANTEE" OF CLEVELAND RANGE MADE OR IMPLIED IN ANY MANUAL, LITERATURE, ADVERTISING BROCHURE OR OTHER MATERIALS.

Cleveland Range's liability on any claim of any kind, including negligence, with respect to the goods or services covered hereunder, shall in no case exceed the price of the goods or services, or part thereof, which gives rise to the claim. IN NO EVENT SHALL CLEVELAND RANGE BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES IN THE NATURE OF PENALTIES.

LIMITED EXTENDED WARRANTY COVERAGE


The purchase of a Limited Extended Warranty Contract extends the standard warranty coverage to the purchased period of time (one to four years) from the date of installation, start-up, or demonstration, whichever is sooner.

MODEL KGM OPERATING CONTROLS AND INDICATORS

For your better understanding and confidence, the following explanation of the control system on these kettles is offered.

| Item No. | Description | Function |
|-----------------|---|--|
| 34 | On-Off Toggle Switch (Main Body Dwg.) | Controls electric power to kettle. |
| 38 | Solid State Temperature Control Knob (Main Body Dwg.) | This control knob allows the operator to select kettle heat increments from Min. to Max. |
| 37 | Power Indicator Light (Green) (Main Body Dwg.) | When lit, indicates that there is electrical power to the kettle. |
| 36 | Low Water Indicator Light (Red) (Main Body Dwg.) | When lit, indicates that the burners have cut out and the unit requires water. (See jacket filling instructions). |
| 3 | Vacuum/Pressure Gauge (Main Body Dwg.) | Indicates steam pressure in PSI inside the steam jacket as well as vacuum. |
| 20 | Pressure Relief Valve (Main Body Dwg.) | In the unlikely event that there is an excess steam build-up in the jacket, this valve opens automatically to relieve this pressure. |
| 23 | Water Level Indicator (Main Body Dwg.) | This sight glass with "HI" and "LOW" (HI and LO) water level lines shows water level in the steam jacket. |
| 31, 33 | Gas Control Valve (Main Body Dwg.) | Controls main gas supply to the kettle. |

MODEL KGM MAIN BODY



MODEL KGM - MAIN BODY

| Item No. | Part No. | Description | Qty. | Item No. | Part No. | Description | Qty. | |
|----------|----------|--|------|----------|----------|--|---|---|
| 1 | KE50142 | Cover- 40 Gal. (see note*) | 1 | 28 | KE51116 | Pilot Orifice Nat. Gas (.020") | 1 | |
| | KE50143 | Cover- 60 Gal. (see note*) | 1 | | KE51162 | Pilot Orifice L.P. (.0145") | 1 | |
| | KE50144 | Cover- 80 Gal. (see note*) | 1 | 29 | KE51066 | Burner | 2, 3, 4 | |
| | KE50145 | Cover-100 Gal. (see note*) | 1 | 30 | KE51118 | Burner Orifice Nat. Gas (0-2000 ft. elev. #43 drill) | 2, 3, 4 | |
| 2 | KE50151 | Handle Knob | 1 | | SE50065 | Burner Orifice Nat. Gas (2000-4000 ft. elev. #44 drill) | 2, 3, 4 | |
| 3 | KE50429 | Pressure Gauge (incl. Item no. 4) | 1 | | SE50066 | Burner Orifice Nat. Gas (4000-6000 ft. elev. #45 drill) | 2, 3, 4 | |
| 4 | SE50001 | Pressure Gauge Glass Assy. | 1 | | KE51119 | Burner Orifice L.P. (0-2000 ft. elev. #53 drill) | 2, 3, 4 | |
| 5 | KE50556 | Water Level Probe | 1 | | SK50342 | Burner Orifice L.P. (2000-4000 ft. elev. #54 drill) | 2, 3, 4 | |
| 6 | FI05022 | Hex Nipple | 1 | | SE50069 | Burner Orifice L.P. (4000-6000 ft. elev. #55 drill) | 2, 3, 4 | |
| 7 | KE51014 | Check Valve, ½" | 1 | | 31 | KE51155 | Combination Control Valve N.G.-24 VAC (Spark Ignition) | 1 |
| 8 | FI00250 | Street Elbow | 1 | | KE51163 | Combination Control Valve L.P.-24 VAC (Spark Ignition) | 1 | |
| 9 | FI00151 | Plug | 1 | | 32 | KE51159 | Pilot Flame Sensor (Mercury Vapor Type) (Spark Ignition) | 1 |
| 10 | KE00515 | Thermistor | 1 | | 33 | KE51110 | Combination Control Valve N.G.-120 VAC (Manual Ignition) | 1 |
| 11-17 | KE50219 | 1½" Draw-Off Valve Assy. | 1 | | KE51161 | Combination Control Valve L.P.-120 VAC (Manual Ignition) | 1 | |
| | KE50972 | 2" Draw-Off Valve Assy. | 1 | | 34 | KE50504 | Toggle Switch ON/OFF | 1 |
| | KE50973 | 3" Draw-Off Valve Assy. | 1 | | 35 | KE50988 | Potentiometer | 1 |
| 11 | N/A | Body (1½") (see note**) | 1 | | 36 | KE50567 | L.E.D. Red | 1 |
| | N/A | Body (2") (see note****) | 1 | | 37 | KE50568 | L.E.D. Green | 1 |
| | N/A | Body (3") (see note*****) | 1 | | 38 | KE50569 | Knob, Potentiometer | 1 |
| 12 | SE50008 | Stem (1½") | 1 | | 39 | SK50062 | Rubber Boot | 1 |
| | SE50009 | Stem (2") | 1 | | 40 | KE51141 | Transformer-120/16V | |
| | SE50010 | Stem (3") | 1 | | 41 | KE50501 | Transformer-240/16V | |
| 13 | FA00111 | "O" Ring (1½", 2") | 1 | | 42 | KE50753 | Relay, 12V DC | 1 |
| | FA00210 | "O" Ring (3") | 1 | | 43 | KE00459 | Solid State Control Box | 1 |
| 14 | SE50011 | Bonnet (1½") | 1 | | 44 | KE51138 | Safety Thermostat | 1 |
| | SE50012 | Bonnet (2") | 1 | | 45 | KE51164 | Transformer-120/24V | 1 |
| | SE50013 | Bonnet (3") | 1 | | 46 | KE51165 | Transformer-240/24V | 1 |
| 15 | SE50014 | Hex Nut (1½") | 1 | | 47 | KE51167 | Pilot Re-Lite (Spark Ignition) (see note*****) | 1 |
| | SE50015 | Hex Nut (2") | 1 | | 48 | KE51168 | Cycling Pilot Safety Timer (Spark Ignition) (L.P. Only) (see note*****) | 1 |
| | SE50016 | Hex Nut (3") | 1 | | 49 | KE51140 | ¼/10 Amp Fuse (Manual Ignition) | 1 |
| 16 | SE50017 | Knob (1½", 2") | 1 | | | KE51169 | 1½ Amp Fuse (Spark Ignition) | 1 |
| | SE50018 | Knob (3") | 1 | | | SK50055 | Terminal Block Section | 2 |
| 17 | SE50019 | Wing Nut (1½", 2") | 1 | | | SK50054 | Terminal Block End Section | 1 |
| | SE50063 | Knob Hex Nut (3") | 1 | | | | | |
| 18 | FI00598 | Nipple | 1 | | | | | |
| 19 | FI05024 | Coupling | 1 | | | | | |
| 20 | KE51062 | Safety Valve-25 P.S.I. | 1 | | | | | |
| 21 | KE51087 | Blow Down Pipe | 1 | | | | | |
| 22 | FA00033 | "O" Ring, Sight Glass | 1 | | | | | |
| 23 | KE51053 | Sight Glass | 1 | | | | | |
| 24 | KE50955 | Sight Glass Retaining Cover | 1 | | | | | |
| 25 | KE51114 | Pilot Burner | 1 | | | | | |
| 26 | KE51160 | Ignition Electrode | 1 | | | | | |
| 27 | KE51111 | Pilot Flame Sensor (Thermopile Type) (Manual Ignition) | 1 | | | | | |
| | KE51159 | Pilot Flame Sensor (Mercury Vapor Type) (Spark Ignition) | 1 | | | | | |

KE54941-7

note* Part number is different for full jacketed kettles. Please order by description.

note** Please order KE50219-1½" Draw-Off Valve Assy. (incl. Item No. 11-17)


note*** Please order KE50972-2" Draw-Off Valve Assy. (incl. Item No. 11-17)

note**** Please order KE50973-3" Draw-Off Valve Assy. (incl. Item No. 11-17)


note***** Pilot Re-Lite and Cycling Pilot Safety Timer may be combined as one control cat. No. 50A22-1, Cleveland Part No. KE51405

KETTLE AND SKILLET FAUCET

| Item No. | Part No. | Description | Qty. | Item No. | Part No. | Description | Qty. |
|----------|-----------|---|------|----------|----------|--|------|
| 1 | SE50020 | Hot Water Stem Assy. | 1 | 10 | KE51403 | Double Pantry Control Valve (incl. Item No. 1, 2, 3) | 1 |
| 2 | SE50021 | Cold Water Stem Assy. | 1 | 11 | N/A | Old Style Single Pantry Control Valve (please order Item No. 4, 5, 6, 7, 9) | 1 |
| 3 | SE50022 | Yoke Connection Kit | 1 | | N/A | Old Style Double Pantry Control Valve (please order Item No. 4, 5, 6, 7, 10) | |
| 4 | FA00016 | "O" Ring | 1 | 12 | N/A | 1" Spout (please order Item No. 4, 5, 6, 7, 14) | 1 |
| 5 | FA95022 | Retaining Ring | 1 | 13 | FA00115 | "O" Ring | 2 |
| 6 | SE50064 | Spout Nut | 1 | 14 | SE50061 | Adapter (to adapt new style spout to old style control valve) | 1 |
| 7 | see chart | 3/4" spout (please see 3/4" spout chart below) | 1 | | | | |
| 8 | N/A | 3/4" spout with Aerator (please order Item No. 4, 5, 6, 7) | 1 | | | | |
| 9 | KE51401 | Single Pantry Control Valve (incl. Item No. 2) | 1 | | | | |




| A | B | Part No. |
|---------|-----|----------|
| 4" | 8" | KE50833 |
| 10" | 9" | KE50832 |
| 6" | 22" | KE50831 |
| 12 1/2" | 14" | KE50830 |
| 10 3/4" | 14" | KE50829 |
| 5" | 14" | KE50828 |
| 24" | 9" | KE50827 |
| 20" | 9" | KE50826 |
| 12 1/2" | 9" | KE50825 |



Use only replacement parts which are factory supplied as to preserve the certification of Underwriters Laboratories, American Gas Association, Canadian Standards Association or Canadian Gas Association (as applicable). The use of other than factory supplied replacement parts will void the warranty.

HINGE ASSEMBLY FOR GAS KETTLES



| Item No. | Part No. | Description | Qty. |
|----------|----------|---------------------------------|------|
| 1-9 | KE00598 | Hinge Assy. (40 gal. and under) | 1 |
| | KE00677 | Hinge Assy. (60 gal. and over) | 1 |
| 1 | KE51218 | Body Spring Assist Hinge | 1 |
| 2 | KE50824 | Hinge Bearing | 1 |
| 3 | KE50823 | Pin (Hinge) | 1 |
| 4 | KE50820 | Insert Brass Adjust | 1 |
| 5 | KE50819 | End Piece | 1 |
| 6 | FA11507 | Screws Adjust | 2 |
| 7 | FA11284 | Bolts End Block | 2 |
| 8 | KE50122 | Spring (40 gal. and under) | 1 |
| | KE50121 | Spring (60 gal. and over) | 1 |
| 9 | KE50821 | Cylinder (40 gal. and under) | 1 |
| | KE00653 | Cylinder (60 gal. and over) | 1 |
| 10 | KE50151 | Knob Ball Type | 1 |
| 11 | | Cover Handle (Specify Model) | 1 |
| 12 | KE00095 | Lid Holder | 1 |
| 13 | FA30500 | Washer Lid Holder | 1 |
| 14 | FA11223 | Bolt Lid Holder | 1 |

Use only replacement parts which are factory supplied as to preserve the certification of Underwriters Laboratories, American Gas Association, Canadian Standards Association or Canadian Gas Association (as applicable). The use of other than factory supplied replacement parts will void the warranty.

GAS KETTLE SERVICING GUIDE

This section contains servicing information intended for use by Authorized Service Personnel.

Note: If Fault Isolation Procedure is needed, be sure to start at step #1.

A/ PROBLEM: Kettle is not heating at all. (Burners fail to ignite) (Kettle must be on and temperature control set).

Possible Causes

1. No power — either gas or electric.
2. Low water condition.
3. Defective on/off switch.
4. Defective 24 VAC transformer.
5. Defective 16 VAC transformer.
6. Defective safety thermostat.
7. Defective 12 VDC relay.
8. Defective low water probe.
9. Defective thermistor.
10. Defective potentiometer.
11. Defective or incorrectly adjusted control box.
12. Defective pilot flame sensor.
13. Defective pilot re-light.
14. Defective cycling pilot safety timer.
15. Defective or incorrectly adjusted gas control valve.
16. Blown 4/10 or 1½ amp fuse.
17. Poor ground.
18. Incorrect spark gap.
19. Faulty wiring.

Fault Isolation Procedure

| Step | Test | Result | Remedy |
|------|---|--------|----------------------------------|
| 1. | Are both gas and electrical supplies on? (120 VAC at terminal block) | Yes | Go to step #2 |
| | | No | Correct external power supply. |
| 2. | Is red LED illuminated? | Yes | Follow kettle filling procedure. |
| | | No | Go to step #3. |
| 3. | Is green LED illuminated? | Yes | Go to step #4. |
| | | No | Go to step #8. |
| 4. | Is 24 VAC present at output of 24 V transformer? Or if manual ignition, is 120 VAC present at gas control valve? | Yes | Go to step #14. |
| | | No | Go to step #5. |
| 5. | Is there 12-16 VDC at circuit path #8? SEE NOTE * SEE NOTE ** | Yes | Go to step #6. |
| | | No | Go to step #8. |

| | | | |
|-----|---|-----|--|
| 6. | Is 120 VAC present across 12 VDC relay contacts? | Yes | Replace defective 12 VDC relay. |
| | | No | Go to step #7. |
| 7. | Is 120 VAC present across safety thermostat? | Yes | Replace defective safety thermostat. |
| | | No | Replace defective 24 V transformer. |
| 8. | Remove on/off switch wiring. Is there proper continuity when switch is activated? | Yes | Go to step #9. |
| | | No | Replace defective on/off switch. |
| 9. | Is there 16 VAC present across the output of the 16 V transformer? | Yes | Go to step #10. |
| | | No | Replace defective 16 V transformer. |
| 10. | Is there ground to circuit path #7 | Yes | Go to step #11. |
| | SEE NOTE* | No | Correct poor ground connection |
| 11. | Is there continuity between ground and circuit path #5? | Yes | Go to step #12. |
| | SEE NOTE * | No | Replace defective low water cut-off probe. |
| 12. | Measure continuity across the potentiometer. Does resistance change while turning the potentiometer knob? | Yes | Go to step #13. |
| | | No | Replace defective potentiometer. |
| 13. | While kettle is cold, remove edge connector from control box. Test resistance on edge connector between pins #2 and #7. Is there approx. 100,000 ohms? | Yes | Replace defective control box. |
| | | No | Replace defective thermistor. |
| 14. | It is assumed that there is proper incoming gas pressure of minimum 7" W.C. for natural gas and 12" W.C. for LP gas. For manual ignition go to step #15. For spark ignition natural gas go to step #19. For spark ignition L.P. gas go to step #25. | | |
| 15. | Is there 120 VAC across the 4/10 amp fuse? | Yes | Replace blown 4/10 amp fuse. |
| | | No | Go to step #16. |

| | | | |
|-----|--|-----|---|
| 16. | Can a pilot be achieved? | Yes | Go to step #17. |
| | | No | Refer to pilot adjustment procedure. If adjustment of pilot is unsuccessful, replace defective gas control valve. |
| 17. | Do burners fail to ignite? | Yes | Go to step #18. |
| | | No | Refer to "kettle heats too slowly" servicing guide. |
| 18. | Does the pilot flame sensor (thermopile) generate 450-750 mV? | Yes | Replace defective gas control valve. |
| | | No | Replace defective pilot flame sensor (thermopile). |
| 19. | Can a pilot be achieved? | Yes | Go to step #24. |
| | | No | Go to step #20. |
| 20. | Is the pilot re-light generating a spark? | Yes | Go to step #23. |
| | | No | Go to step #21. |
| 21. | Is there 24 VAC across the 1½ amp fuse? | Yes | Replace blown 1½ amp fuse. |
| | | No | Go to step #22. |
| 22. | Is the spark gap ⅛" ± 1/32"? | Yes | Replace defective pilot re-light. |
| | | No | Adjust spark gap. |
| 23. | Measure continuity across pilot flame sensor's pins #3 and #4. Is it a closed circuit? | Yes | Replace defective gas control valve. |
| | | No | Replace defective pilot flame sensor. |
| 24. | After pilot has been lit for 5 minutes, pull pilot flame sensor's connection off and quickly measure continuity between pins #2 and #4. Is it a closed circuit at first and after pilot flame sensor cools down the circuit opens? | Yes | Replace defective gas control valve. |
| | | No | Replace defective pilot flame sensor. |
| 25. | Can a pilot be achieved? | Yes | Go to step #31. |
| | | No | Go to step #26. |
| 26. | Is the pilot re-light generating a spark? | Yes | Go to step #29. |
| | | No | Go to step #27. |

| | | | |
|-----|--|-----|---|
| 27. | Is there 24 VAC across the 1½ amp fuse? | Yes | Replace blown 1½ amp fuse. |
| | | No | Go to step #28. |
| 28. | Is the spark gap ½" ± 1/32"? | Yes | Go to step #29. |
| | | No | Adjust spark gap. |
| 29. | Turn power on/off switch to "off" for 5 minutes. This will zero cycling pilot safety timer. Then turn unit back on. Is a pilot now achieved? | Yes | If burners now do not ignite, go to step #31. |
| | | No | Go to step #30. |
| 30. | Measure continuity across pilot flame sensor's pins #3 and #4. Is it a closed circuit? | Yes | Replace either defective pilot re-light or defective gas control valve. |
| | | No | Replace defective pilot flame sensor. |
| 31. | After pilot has been lit for 5 minutes, pull pilot flame sensor's connection off and quickly measure continuity between pins #2 and #4. Is it a closed circuit at first and after pilot flame sensor cools down the circuit opens? | Yes | Replace defective gas control valve. |
| | | No | Replace defective pilot flame sensor. |

NOTE* Slightly pull off edge connector from control box. Edge connector must still contact with circuit paths. Pin numbers are marked on edge connector.

NOTE** Measure DC to ground.

B/ PROBLEM: Kettle heats too slowly or not hot enough (Note: Operating pressure is 10-12 psi).

Possible Causes

1. Loss of vacuum.
2. Low incoming gas pressure.
3. Defective safety thermostat.
4. Defective potentiometer.
5. Defective thermistor.
6. Defective control box.
7. Defective gas control valve.

Fault Isolation Procedure

| Step | Test | Result | Remedy |
|-------------|---|---------------|----------------------------------|
| 1. | In a cold state, does the pressure guage read "vent air"? | Yes | Follow kettle venting procedure. |
| | | No | Go to step #2. |
| 2. | Do the burners shut off too early? | Yes | Go to step #3. |
| | | No | Go to step #6. |

| | | | |
|----|---|-----|--|
| 3. | After the burners shut off, is the green LED still illuminated? | Yes | Replace defective safety thermostat. |
| | | No | Go to step #4. |
| 4. | Unplug the control box and measure the resistance across the potentiometer. Is the resistance approx. 0 ohms at max. and 50,000 ohms at min? | Yes | Go to step #5. |
| | | No | Replace defective potentiometer. |
| 5. | Remove thermistor from kettle and allow to cool. Remove edge connector from control box. Test resistance on edge connector between pins #2 and #7. Is there approx. 100,000 ohms? NOTE: Pin numbers are marked on edge connector. | Yes | Adjust or replace defective control box. |
| | | No | Replace defective thermistor. |
| 6. | Is there min. 7" W.C. for natural gas or 12" W.C. for LP gas incoming gas pressure? | Yes | Go to step #7 |
| | | No | Correct gas pressure. |
| 7. | Is there 6" W.C. for natural gas or 11" W.C. for LP gas outgoing gas pressure? | Yes | If burners are not operating properly, check gas line, orifices, etc. for obstruction. |
| | | No | Adjust or replace gas control valve. |

C/ PROBLEM: Kettle is overheating.

Possible Causes

1. Defective thermistor
2. Defective potentiometer.
3. Defective 12 VDC relay
4. Defective control box.

| Step | Fault Isolation Procedures Test | Result | Remedy |
|-------------|---|---------------|----------------------------------|
| 1. | Do the burners shut off at all? | Yes | Go to step #3 |
| | | No | Go to step #2 |
| 2. | Does the green LED ever turn off? | Yes | Replace defective 12 VDC relay. |
| | | No | Go to step #3. |
| 3. | Unplug the control box and measure the resistance across the potentiometer. Is the resistance approx. 0 ohms at max. and 50,000 ohms at min.? | Yes | Go to step #4. |
| | | No | Replace defective potentiometer. |

- | | | | |
|----|---|---------------|---|
| 4. | Remove thermistor from kettle and allow to cool. Remove edge connector from control box. Test resistance on edge connector between pins #2 and #7. Is there approx. 100,000 ohms? | Yes No | Adjust or replace defective control box. Repiace defective thermistor. |
|----|---|---------------|---|

NOTE: Pin numbers are marked on edge connector.

D/ PROBLEM: Red LED remains illuminated even though water has been added.

Possible Causes

1. Defective low water probe.
2. Defective control box.
3. Faulty wiring.

Fault Isolation Procedure

| Step | Test | Result | Remedy |
|------|--|---------------|--|
| 1. | Remove wire from low water probe and ground the wire to the body of the unit. Does the red LED turn off? | Yes No | Replace defective low water probe. Check for faulty wiring or poor connection. If this is all correct, replace control box. |

GAS KETTLE RESERVOIR FILL PROCEDURES

The reservoir's water level must be maintained at the proper level. Under normal operating conditions, the sealed water reservoir should never require the addition of water. If the red "low water" light comes on during use, the water level has reached a critically low level. The low water protection control has automatically shut off the gas burners. The following procedure must be completed before further use:

1. Shut off power to the kettle.
2. Remove the front panel.
3. Unscrew and remove the ½" male NPT plug (only) located at the end of the check valve elbow.
4. Hold the safety valve pin out while adding distilled water through the check valve elbow using a funnel. Fill the water jacket until the water level is between the "HI" and "LO" markings on the sight gauge glass.
5. Place the plug into the elbow and carefully tighten. Do not over-tighten. Replace the front panel.
6. Restore power to the kettle.
7. The kettle must now be vented. Refer to the "Kettle Venting Instructions."

CAUTION: It is recommended that only distilled water be used when **adding** water to a partially filled water reservoir. Local tap water conditions may cause kettle damage which is not covered under warranty. If the water reservoir is completely empty, add formula* until the level is between the "HI" and "LO" marks on the sight gauge.

(See chart next page)

***Anti-freeze and rust inhibitor formula:**

| | | | |
|-----------------|--------------------|---|-------|
| Rust Inhibitor: | 3 oz. | = | 0.6% |
| Anti-Freeze: | 64 oz. (.5 gal.) | = | 12.4% |
| Tap Water: | 448 oz. (3.5 gal.) | = | 87.0% |

GAS KETTLE VENTING INSTRUCTIONS

If the vacuum/pressure gauge reading is in the "vent air" zone, it means that air has entered the steam/water jacket, resulting in little or no vacuum. This reduces kettle efficiency by slowing its heating process. To remedy this situation, the following venting procedures should be followed:

1. With the temperature control knob set at number 9, heat the empty kettle until the vacuum/pressure gauge indicates 5-10 psi.
2. Release steam and air from the steam/water jacket by pulling out on the pin of the safety valve for approximately 10-15 seconds.


The kettle's steam/water jacket should now be free of air. At room temperature, the pressure gauge needle should rest in the green zone, indicating a vacuum in the kettle's jacket. To check the gauge for proper vacuum after venting, the temperature can be quickly reduced by filling the kettle with cold water.

If the kettle will not hold a vacuum, have a qualified service technician test for leaks at the water fill plug, the sight gauge, the safety valve, the probe, and the vacuum/pressure gauge fittings. We suggest mixing a 50/50 solution of liquid detergent and water while heating the kettle to at least 5 psi pressure. Then, shut off power to the kettle. The soapy solution should be applied to the suspected area while the gauge shows at least 5 psi pressure. Any bubbles which appear will indicate a leak.


PILOT ADJUSTMENT

CAUTION: The following procedure, as well as all other work on gas controls, should be performed only by a qualified service technician.

1. Remove pilot adjustment cover screw.
2. Turn pilot flow adjustment screw clockwise to decrease or counterclockwise to increase flame (see below drawing for correct flame adjustment).
3. Replace cover screw.




COMBINATION CONTROL VALVE





PILOT GENERATOR

HINGE ADJUSTMENT INSTRUCTIONS



1. Insert $\frac{3}{8}$ " Allen wrench.
2. Turn clockwise to relieve tension on spring.
3. While tension is released remove one of the two slotted screws.
4. To prevent Allen wrench from springing back abruptly while the second slotted screw is removed, insert a pin (approximately $\frac{1}{8}$ ") in the hole where the first slotted screw was removed from.
5. Remove second slotted screw.
6. While holding Allen wrench remove pin.
7. Turn Allen wrench clockwise to tighten or counter-clockwise to loosen tension to produce desired effect.
8. Re-insert pin in one of the two holes.
9. Tighten one slotted screw in the other hole (it may be necessary to turn Allen wrench slightly to align holes.)
10. Remove pin and repeat step number 9 for other slotted screw.

WIRING DIAGRAM FOR GAS FIRED STEAM JACKETED KETTLES



NOTE - Thermocouple is part of the gas control valve; therefore not shown on this electrical diagram.

NOTE - Pilot re-light and cycling pilot safety timer may be combined as one control. Cat. No. 50A22-1

NOTE - 24 V.A.C. transformer not used with 120 V.A.C. gas control valve

