

FROM TERMINAL BLOCKS EXTERNAL WIRING

FIELD CONSOLE CONTROL PANEL

FIELD CONSOLE	CONTROL PANEL
N	N
1 103	103 103
2 STEAM SOLENOID	116 103
3 DUMP SOLENOID	118 116
4 COOLING IN SOLENOID	115 118
5 COOLING OUT SOLENOID	115 115
6 CONDENSATE RETURN SOLENOID	119 115
7 120VAC FAN CONSOLE	102 119
8 COVER LIMIT SWITCH	158 102
9 (OPTIONAL) AGITATOR LIMIT SWITCH	158 158
10 E-STOP MIXER	158A 158A
11 THERMORESISTOR	158A 158A
12 RTD SENSOR	162A 158A
13 WATER METER	162A 162A
14 SOLENOID COLD WATER	162A 162A
15 SOLENOID HOT WATER	162 162A
16 POWER 120VAC	162 162
17	116 116
18	117 116
19	125 117
20	126 125
21	104 126
22	132 104
23	137 132
	139 137
	140 139
	140 140
	102 140
	102 102

21C*#18 RED